

# Palm User Manual & Tips

Embrace the journey.

At Loren, we believe in the power of exploration- of your desires, your boundaries, and everything in between. This user manual is here to help you get the most out of your Loren product.

**Your pleasure is your journey. Take it at your own pace, follow your curiosity, and remember: there's no right or wrong way to enjoy. Just what feels good for you.**

## Awaken your senses

Turn Palm on and glide its compact head over your clitoris or other external spots to gently awaken your senses. Its targeted vibrations are perfect for building arousal.



## Find your perfect vibe

Explore Palm's range of vibration settings to discover what works best for you. Start with a gentle hum and gradually increase the intensity to match your mood.



## Take it anywhere

Palm's pocket-sized design makes it perfect for on-the-go pleasure. Whether in the shower (it's waterproof!) or in bed, let its versatility inspire your exploration.

## First thing first:

### Safety lock feature

To unlock its magic, simply press and hold the power button for 3 seconds.

### Flexible tip stimulation



**Power Button**  
Press to cycle the 9 different patterns.



**Charging port**

## More info:

### Vibrator care

Your Palm deserves a little TLC! Rinse it with water and mild soap, then pat it dry. Quick, easy, and ready for your next adventure—clean it before and after every use.

### Special instructions

Do not turn on while charging and/or cleaning. (while charging the light will flash; the light will turn solid when fully charged) Low battery alert: Light will flash rapidly when battery is running low. Use only 5-volt USB wall adapter (standard mobile phone charger). Allow 60 minutes for full charge. Use water based lubricant only.

### Warnings

Discontinue use if there is any discomfort for you or for your partner.

## FAQ's

**What makes Palm unique compared to other mini massagers?**

Palm's compact size, sleek design, and powerful vibrations strike the ideal balance between convenience and intensity. It's easy to use, travel-ready, and perfect for precise, targeted pleasure.

**Can Palm be used on different areas of the body?**

Yes! Palm is perfect for clitoral stimulation but can also be used to tease other external areas, like the nipples or the entrance of the vagina.